


A

No.	Código	Clave	Descripción
1	900568	R1-MOT-16/18/20	Tornillo
2	900569	R2-MOT-16/18/20	Bujía
3	900570	R3-MOT-16/18/20	Cilindro
4	900571	R4-MOT-16/18/20	Anillo de pistón
5	900572	R5-MOT-16/18/20	Pistón
6	900573	R6-MOT-16/18/20	Seguros de perno de pistón
7	900574	R7-MOT-16/18/20	Perno de pistón
8	900575	R8-MOT-16/18/20	Sinfin izquierdo
9	900576	R9-MOT-16/18/20	Bomba de aceite
10	900577	R10-MOT-16/18/20	Perno
11	900578	R11-MOT-16/18/20	Arandela de clutch
12	900579	R12-MOT-16/18/20	Clutch
13	900580	R13-MOT-16/18/20	Tambor de clutch
14	900581	R14-MOT-16/18/20	Balero de rodillos
15	900582	R15-MOT-16/18/20	Arandela tapa
16	900583	R16-MOT-16/18/20	Seguro "E"
17	900584	R17-MOT-16/18/20	Tapa de la bomba de aceite
18	900585	R18-MOT-16/18/20	Abrazadera
19	900586	R19-MOT-16/18/20	Toma de combustible
20	900587	R20-MOT-16/18/20	Sello del adaptador del carburador
21	900588	R21-MOT-16/18/20	Adaptador del carburador
22	900589	R22-MOT-16/18/20	Arandela reten
23	900590	R23-MOT-16/18/20	Tornillo #8-16x5/16"
24	900591	R24-MOT-16/18/20	Tornillo torx
25	900592	R25-MOT-16/18/20	Anillo sellador
26	900593	R26-MOT-16/18/20	Placa guía de la barra
27	900594	R27-MOT-16/18/20	Tuerca
28	900595	R28-MOT-16/18/20	Tapa del clutch
29	900596	R29-MOT-16/18/20	Empaque de carburador
30	900597	R30-MOT-16/18/20	Carburador
31	900598	R31-MOT-16/18/20	Base del filtro de aire
32	900599	R32-MOT-16/18/20	Tornillo 10-32x1.75
33	900600	R33-MOT-16/18/20	Filtro de aire
34	900601	R34-MOT-16/18/20	Tornillo 8-16x5/8
35	900602	R35-MOT-16/18/20	Deflector del carburador
36	900603	R36-MOT-16/18/20	Rodillo
37	900604	R37-MOT-16/18/20	Perno
38	900605	R38-MOT-16/18/20	Eslabón
39	900606	R39-MOT-16/18/20	Perno de protector de mano
40	900607	R40-MOT-16/18/20	Tornillo 8-32x5/8
41	900608	R41-MOT-16/18/20	Pivote derecho




A



Línea de comunicación directa
 CENTRO DE SERVICIO AUTORIZADO TRUPER
800-018-7873 En México

B


No.	Código	Clave	Descripción
42	900609	R42-MOT-16/18/20	Protector/freno de cadena
43	900610	R43-MOT-16/18/20	Pivote izquierdo
44	900611	R44-MOT-16/18/20	Tornillo 8-16x5/8"
45	900612	R45-MOT-16/18/20	Codo del freno de cadena
46	900613	R46-MOT-16/18/20	Deslizador del freno de cadena
47	900614	R47-MOT-16/18/20	Tapa del freno de cadena
48	900615	R48-MOT-16/18/20	Resorte de compresión
49	900616	R49-MOT-16/18/20	Protector anticontragolpe
50	900617	R50-MOT-16/18/20	Perno
51	900618	R51-MOT-16/18/20	Freno de cadena
52	900619	R52-MOT-16/18/20	Seguro "E"
53	900620	R53-MOT-16/18/20	Resorte del protector de mano
54	900621	R54-MOT-16/18/20	Tornillo #10-14x1/2"
55	900622	R55-MOT-16/18/20	Sosten de la cadena
56	900623	R56-MOT-16/18/20	Tornillo
57	900624	R57-MOT-16/18/20	Remache
58	900625	R58-MOT-16/18/20	Manguera
59	900626	R59-MOT-16/18/20	Manguera
60	900627	R60-MOT-16/18/20	Palanca del ahogador
61	16636	R61-CAMO-16	Cadena de 16" p/motosierra
61	16637	R61-CAMO-18	Cadena de 18" p/motosierra
61	16638	R61-CAMO-20	Cadena de 20" p/motosierra
62	16632	R62-BAMO-16	Barra de 16" p/motosierra
62	16633	R62-BAMO-18	Barra de 18" p/motosierra
62	16634	R62-BAMO-20	Barra de 20" p/motosierra
63	900628	R63-MOT-16/18/20	Placa guía de la barra
64	900629	R64-MOT-16/18/20	Ajustador de perno
65	900630	R65-MOT-16/18/20	Tornillo #10-24x1/8"
66	900631	R66-MOT-16/18/20	bulbo cebador
67	900632	R67-MOT-16/18/20	Manguera
68	900633	R68-MOT-16/18/20	Cable del acelerador
69	900634	R69-MOT-16/18/20	Buje de hule
70	900635	R70-MOT-16/18/20	Interruptor de encendido
71	900636	R71-MOT-16/18/20	Panel de controles
72	900637	R72-MOT-16/18/20	Chasis
73	900638	R73-MOT-16/18/20	Filtro de gasolina
74	900639	R74-MOT-16/18/20	Tornillo
75	900640	R75-MOT-16/18/20	Arandela
76	900641	R76-MOT-16/18/20	Sujetador de plástico
77	900642	R77-MOT-16/18/20	Anillo de goma
78	900643	R78-MOT-16/18/20	Tornillo #10-14x5/8"



B

C



No.	Código	Clave	Descripción
79	900645	R79-MOT-16/18/20	Tapón del tanque de combustible
80	900646	R80-MOT-16/18/20	Resorte amortiguador
81	900647	R81-MOT-16/18/20	Tornillo
82	900648	R82-MOT-16/18/20	Mango trasero
83	900649	R83-MOT-16/18/20	Liberador del gatillo
84	900650	R84-MOT-16/18/20	Resorte de tensión
85	900651	R85-MOT-16/18/20	Gatillo del acelerador
86	900652	R86-MOT-16/18/20	Tornillo #10-24x5/8"
87	900653	R87-MOT-16/18/20	Cubierta del mango trasero
88	900654	R88-MOT-16/18/20	Tapón plástico
89	900655	R89-MOT-16/18/20	Tornillo
90	900656	R90-MOT-16/18/20	Resorte amortiguador
91	900657	R91-MOT-16/18/20	Placa de amortiguador
92	900658	R92-MOT-16/18/20	Zincho de amortiguador
93	900659	R93-MOT-16/18/20	Mango frontal
94	900660	R94-MOT-16/18/20	Tornillo
95	900661	R95-MOT-16/18/20	Carcasa con sistema de arranque
95.1	900662	R95.1-MOT-16/18/20	Carcasa de arranque
95.2	900663	R95.2-MOT-16/18/20	Manija de arranque
95.3	900664	R95.3-MOT-16/18/20	Piola
95.4	900665	R95.4-MOT-16/18/20	Buje
95.5	900666	R95.5-MOT-16/18/20	Tornillo
95.6	900667	R95.6-MOT-16/18/20	Tapa de resorte de polea
95.7	900668	R95.7-MOT-16/18/20	Resorte
95.8	900669	R95.8-MOT-16/18/20	Polea
95.9	900670	R95.9-MOT-16/18/20	Tapa de resorte de tensión
95.10	900671	R95.10-MOT-16/18/20	Resorte de tensión
96	900672	R96-MOT-16/18/20	Pre filtro de aire
97	900673	R97-MOT-16/18/20	Carcasa del rotor
98	900674	R98-MOT-16/18/20	Filtro
99	900675	R99-MOT-16/18/20	Válvula
100	900676	R100-MOT-16/18/20	Tuerca especial
101	900677	R101-MOT-16/18/20	Tapón del aceite de cadena
102	900678	R102-MOT-16/18/20	Anillo de goma
103	900679	R103-MOT-16/18/20	Tuerca hexagonal
104	900680	R104-MOT-16/18/20	Tornillo #10-14x1/2"
105	900681	R105-MOT-16/18/20	Guía de corte
106	900682	R106-MOT-16/18/20	Tornillo #10-24x5/8"
107	900683	R107-MOT-16/18/20	Pernos de montaje de la barra
108	900684	R108-MOT-16/18/20	Tuerca de seguridad



C

D

No.	Código	Clave	Descripción
109	900685	R109-MOT-16/18/20	Arandela plana
110	900686	R110-MOT-16/18/20	Pivote de salida de aceite
111	900687	R111-MOT-16/18/20	Rotor
112	900688	R112-MOT-16/18/20	Buje espaciador
113	900689	R113-MOT-16/18/20	Sello de flecha
114	900690	R114-MOT-16/18/20	Tapa de baleros
115	900691	R115-MOT-16/18/20	Balero de bolas 6201
116	900692	R116-MOT-16/18/20	Carter
117	900693	R117-MOT-16/18/20	Cigüeñal y biela
117.1	900694	R117.1-MOT-16/18/20	Biela con baleros de rodillos
117.2	900695	R117.2-MOT-16/18/20	Perno
118	900696	R118-MOT-16/18/20	Resorte cónico
119	900697	R119-MOT-16/18/20	Manguera para aceite de cadena
120	900698	R120-MOT-16/18/20	Tornillo
121	900699	R121-MOT-16/18/20	Cable de encendido
122	900700	R122-MOT-16/18/20	Bobina
123	900701	R123-MOT-16/18/20	Tuerca
124	900702	R124-MOT-16/18/20	Silenciador
125	900703	R125-MOT-16/18/20	Empaque de silenciador
126	900704	R126-MOT-16/18/20	Placa de silenciador
127	900705	R127-MOT-16/18/20	Tornillo
128	900706	R128-MOT-16/18/20	Carcasa de cilindro
129	900707	R129-MOT-16/18/20	Tornillo #6-19x1/2"



D