

No.	Código	Clave	Descripción
3	929828	R3-TPN-776X-2	Sello
3.1	929829	R3.1-TPN-776X-2	Arandela
5	929830	R5-TPN-776X-2	Tornillo
6	929831	R6-TPN-776X-2	Retén
8	929832	R8-TPN-776X-2	Resorte
9	929833	R9-TPN-776X-2	Conexión para aire
54	929834	R54-TPN-776X-2	Filtro de malla
10	929835	R10-TPN-776X-2	Arandela con tuerca
11	929836	R11-TPN-776X-2	Resorte
12	929837	R12-TPN-776X-2	Arandela
13	929838	R13-TPN-776X-2	Valvula de escape
14	929839	R14-TPN-776X-2	Filtro de malla
15	929840	R15-TPN-776X-2	Seguro C
16	929841	R16-TPN-776X-2	Balero de bolas 6002
17	929842	R17-TPN-776X-2	Retén
18	929843	R18-TPN-776X-2	Sello
19	929844	R19-TPN-776X-2	Placa frontal
20	929845	R20-TPN-776X-2	Sello 5 mm
21	929846	R21-TPN-776X-2	Rotor
22	929847	R22-TPN-776X-2	Aspas de rotor
23	929848	R23-TPN-776X-2	Cilindro
24	929849	R24-TPN-776X-2	Perno
25	929850	R25-TPN-776X-2	Perno
26	929851	R26-TPN-776X-2	Placa trasera
27	929852	R27-TPN-776X-2	Junta
28	929853	R28-TPN-776X-2	Tapa trasera
29	929854	R29-TPN-776X-2	Perilla de cambio de giro
30	929855	R30-TPN-776X-2	Perno
31	929856	R31-TPN-776X-2	Manga
32	929857	R32-TPN-776X-2	Resorte
33	929858	R33-TPN-776X-2	Arandela de presión
34	929859	R34-TPN-776X-2	Tornillo
36	929860	R36-TPN-776X-2	Válvula de retroceso
37	929861	R37-TPN-776X-2	Sello
38	929862	R38-TPN-776X-2	Tornillo
39	929863	R39-TPN-776X-2	Mofle
40	929864	R40-TPN-776X-2	Cubierta de escape
41	929865	R41-TPN-776X-2	Tornillo
42	929866	R42-TPN-776X-2	Caja de martillo
43	929867	R43-TPN-776X-2	Martillo
44	929868	R44-TPN-776X-2	Perno
45	929869	R45-TPN-776X-2	Flecha
46	929870	R46-TPN-776X-2	Sello
47	929871	R47-TPN-776X-2	Anillo de retención
48	929872	R48-TPN-776X-2	Junta
49	929873	R49-TPN-776X-2	Buje
50	929874	R50-TPN-776X-2	Carcasa de martillo
51	929875	R51-TPN-776X-2	Retén
NS-A	929876	RNS-A-TPN-776X-2	Ensamble de carcasa A
NS-B	929877	RNS-B-TPN-776X-2	Ensamble de válvula de aceleración B
NS-E	929878	RNS-E-TPN-776X-2	Ensamble de gatillo E

