



A

No.	Código	Clave	Descripción
1	934922	R1-MOT-4518P	Tornillo St5x9
2	934923	R2-MOT-4518P	Tanque de combustible
3	934924	R3-MOT-4518P	Sub ensamble de tapa
4	934925	R4-MOT-4518P	Sello
5	934926	R5-MOT-4518P	Tapón combustible
6	934927	R6-MOT-4518P	Almohadilla de goma
7	934928	R7-MOT-4518P	Tornillo
8	934929	R8-MOT-4518P	Tapón
9	934930	R9-MOT-4518P	Amortiguador plástico
10	934931	R10-MOT-4518P	Tornillo St 8x16
11	934932	R11-MOT-4518P	Empuñadura
12	934933	R12-MOT-4518P	Bulbo cebador
13	934934	R13-MOT-4518P	Seguro del acelerador
14	934935	R14-MOT-4518P	Resorte del acelerador
15	934936	R15-MOT-4518P	Acelerador
16	934937	R16-MOT-4518P	Perno de acelerador
17	934938	R17-MOT-4518P	Cubierta de la empuñadura
18	934939	R18-MOT-4518P	Tubo de re retorno de aceite
19	934940	R19-MOT-4518P	Equilibrador
20	934941	R20-MOT-4518P	Balancín
21	934942	R21-MOT-4518P	Filtro de combustible
22	934943	R22-MOT-4518P	Casco de filtro de combustible
23	934944	R23-MOT-4518P	Manguera de combustible
24	934945	R24-MOT-4518P <td Cojinete reductor de impacto	
25	934946	R25-MOT-4518P	Tornillo M5x50
26	934947	R26-MOT-4518P	Conector al carburador
27	934948	R27-MOT-4518P	Perno
28	934949	R28-MOT-4518P	Varilla de acelerador
29	934950	R29-MOT-4518P	Cubierta superior
30	934951	R30-MOT-4518P	Tornillo M5x14




A



**B**


No.	Código	Clave	Descripción
31	934952	R31-MOT-4518P	Junta de filtro de aire
32	934953	R31-MOT-4518P	Filtro de aire
33	934954	R33-MOT-4518P	Cubierta del filtro de aire
34	934955	R34-MOT-4518P	Junta de la perilla del filtro de aire
35	934956	R35-MOT-4518P	Perilla del filtro de aire
36	934957	R36-MOT-4518P	Manguera entrada de aceite
37	934958	R37-MOT-4518P	Resorte de manguera entrada de aceite
38	934959	R38-MOT-4518P	Carburador
39	934960	R39-MOT-4518P	Brida del carburador
40	934961	R40-MOT-4518P	Junta de aislamiento
41	934962	R41-MOT-4518P	Soporte del carburador
42	934963	R42-MOT-4518P	Hoja de aislamiento
43	934964	R43-MOT-4518P	Tornillo Xt 4.2x12
44	934965	R44-MOT-4518P	Almohadilla de goma
45	934966	R45-MOT-4518P	Perilla de estrangulación
46	934967	R46-MOT-4518P	Cubierta perilla de estrangulación
47	934968	R47-MOT-4518P	Almohadilla de goma
48	934969	R48-MOT-4518P	Almohadilla de goma derecha
49	934970	R49-MOT-4518P	Ensamble derecho de cárter
50	934971	R50-MOT-4518P	Soporte de plástico
51	934972	R51-MOT-4518P	Balero de bolas 6202
52	934973	R52-MOT-4518P	Malla friltro de aceite
53	934974	R53-MOT-4518P	Soporte del filtro de aceite
54	934975	R54-MOT-4518P	Retén 15x25x4.5
55	934976	R55-MOT-4518P	Sello de esponja
56	934977	R56-MOT-4518P	Manguera al filtro de aire
57	934978	R57-MOT-4518P	Bomba de aceite
58	934979	R58-MOT-4518P	Ensamble de clutch
61	934980	R61-MOT-4518P	Arandel del clutch
62	934981	R62-MOT-4518P	Tambor del clutch



**B**

C


No.	Código	Clave	Descripción
63	934982	R63-MOT-4518P	Rueda dentada
64	934983	R64-MOT-4518P	Balero de agujas
65	934984	R65-MOT-4518P	Engrane
66	934985	R66-MOT-4518P	Tornillo M4x12
67	934986	R67-MOT-4518P	Cubierta de la bomba de aceite
68	934987	R68-MOT-4518P	Salida de la bomba de aceite
69	934988	R69-MOT-4518P	Tornillo M5x20
70	934989	R70-MOT-4518P	Colector de cadena
71	934990	R71-MOT-4518P	Soporte del amortiguador
72	934991	R73-MOT-4518P	Amortiguador
73	934992	R73-MOT-4518P	Tornillo M4x10
74	934993	R74-MOT-4518P	Cubierta de la salida de aceite
74.1	934994	R74.1-MOT-4518P	Separador
75	934995	R74-MOT-4518P	Soporte derecho
76	934996	R76-MOT-4518P	Perno con cuerda
77	934997	R77-MOT-4518P	Espiga
78	934998	R78-MOT-4518P	Filtro de la aguja de respirador
79	934999	R79-MOT-4518P	Seguro de la aguja
80	935000	R80-MOT-4518P	Aguja de respiración
81	935001	R81-MOT-4518P	Aro de carburador
82	935002	R82-MOT-4518P	Tornillo M5x14
83	935003	R83-MOT-4518P	Manga de entrada
84	935004	R84-MOT-4518P	Bujía
85	935005	R85-MOT-4518P	Junta
86	935006	R86-MOT-4518P	Cilindro
87	935007	R87-MOT-4518P	Tornillo M5x87
88	935008	R88-MOT-4518P	Junta del mofle
89	935009	R89-MOT-4518P	Mofle
90	935010	R90-MOT-4518P	Tornillo M5x10
91	935011	R91-MOT-4518P	Cubierta de mofle



C

D

No.	Código	Clave	Descripción
92	935012	R92-MOT-4518P	Tuerca M5
93	935013	R93-MOT-4518P	Junta del cilindro
94	935014	R94-MOT-4518P	Anillo del pistón
95	935015	R95-MOT-4518P	Perno del pistón
96	935016	R96-MOT-4518P	Pistón
97	935017	R97-MOT-4518P	Seguro del perno de pistón
98	935018	R98-MOT-4518P	Balero de agujas 11x15x12.5 mm
99	935019	R99-MOT-4518P	Ensamble de la biela y cigüeñal
100	935020	R100-MOT-4518P	Arandela espaciadora
101	935021	R101-MOT-4518P	Cuña 3x10
102	935022	R102-MOT-4518P	Perno
103	935023	R103-MOT-4518P	Junta del cárter
104	935024	R104-MOT-4518P	Abrazadera de la manguera
105	935025	R105-MOT-4518P	Ensamble de la manguera
107	935026	R107-MOT-4518P	Cable del switch
108	935027	R108-MOT-4518P	Bobina de ignición
109	935028	R109-MOT-4518P	Tornillo M5x20
110	935029	R110-MOT-4518P	Tornillo M5x25
111	935030	R111-MOT-4518P	Tornillo M5x30
112	935031	R112-MOT-4518P	Sello del tapón de aceite
113	935032	R113-MOT-4518P	Tapón de aceite
114	935033	R114-MOT-4518P	Seguro
115	935034	R115-MOT-4518P	Retén 15x35x4.5
116	935035	R116-MOT-4518P	Tapa
117	935036	R117-MOT-4518P	Tornillo M4x6
118	935037	R118-MOT-4518P	Rotor
119	935038	R119-MOT-4518P	Tuerca M8
120	935039	R120-MOT-4518P	Alojamiento de interruptor
121	935040	R121-MOT-4518P	Soporte del interruptor




D





E

No.	Código	Clave	Descripción
122	935041	R122-MOT-4518P	Interruptor
123	935042	R123-MOT-4518P	Almohadilla de goma exterior
124	935043	R124-MOT-4518P	Almohadilla de goma izquierda
125	935044	R125-MOT-4518P	Ensamble izquierdo del carter
126	935045	R126-MOT-4518P	Seguro Ø3
128	935046	R128-MOT-4518P	Perno 3x9
129	935047	R129-MOT-4518P	Freno del muelle del empujador A
130	935048	R130-MOT-4518P	Perno 3x8
131	935049	R131-MOT-4518P	Tuerca hexagonal M8
132	935050	R132-MOT-4518P	Freno de muelle del empujador B
133	935051	R133-MOT-4518P	Amortiguador
134	935052	R134-MOT-4518P	Tapa del clutch
135	935053	R135-MOT-4518P	Correa de caucho
136	935054	R136-MOT-4518P	Resorte Actuador I
137	935055	R137-MOT-4518P	Resorte Actuador II
138	935056	R138-MOT-4518P	Freno
139	935057	R139-MOT-4518P	Cubierta del resorte
140	935058	R140-MOT-4518P	Tornilla St 4.2x9.5
141	935059	R141-MOT-4518P	Placa de la barra
142	935060	R142-MOT-4518P	Seguro Ø4
143	935061	R143-MOT-4518P	Arandela plana
144	935062	R144-MOT-4518P	Ensamble del freno I
145	935063	R145-MOT-4518P	Aro de hule
146	935064	R146-MOT-4518P	Ensamble del freno II
147	935065	R147-MOT-4518P	Diente de ajuste
148	935066	R148-MOT-4518P	Sin fin de ajuste
149	935067	R149-MOT-4518P	Resorte del freno
150	935068	R150-MOT-4518P	Rueda dentada de ajuste
151	935069	R151-MOT-4518P	Pin hueco
152	935070	R152-MOT-4518P	Pin de nivel I



E

F

No.	Código	Clave	Descripción
153	935071	R153-MOT-4518P	Pin de nivel II
154	935072	R154MOT-4518P	Freno
155	935073	R155-MOT-4518P	Deflector
156	935074	R156-MOT-4518P	Arandela
157	935075	R157-MOT-4518P	Cubierta principal de sistema de arranque
158	935076	R158-MOT-4518P	Resorte principal del sistema de arranque
159	935077	R159-MOT-4518P	Polea de arranque
160	935078	R160-MOT-4518P	Cubierta de arranque
161	935079	R161-MOT-4518P	Resorte de la cubierta de arranque
162	935080	R162-MOT-4518P	Protector plástico
163	935081	R163-MOT-4518P	Cubierta del sistema de arranque
164	935082	R164-MOT-4518P	Cuerda
165	935083	R165-MOT-4518P	Empuñadura de arranque



F

