

A

No.	Código	Clave	Descripción
1	943687	R1-ROTI-12P	Tornillo Especial Izquierdo
2	943688	R2-ROTI-12P	Broquero 3/8
3	943689	R3-ROTI-12P	Caja de Engrane
4	943690	R4-ROTI-12P	Arandela de presión
5	943691	R5-ROTI-12P	Tornillo
5.1	943692	R5.1-ROTI-12P	Anillo Adaptador
6	943693	R6-ROTI-12P	Engrane de Motor
7	943694	R7-ROTI-12P	Motor CD
8	943695	R8-ROTI-12P	Inductor
9	943696	R9-ROTI-12P	Luz de LED
10	943697	R10-ROTI-12P	Botón de Cambios
11	943698	R11-ROTI-12P	Interruptor
12	943699	R13-ROTI-12P	Conector Rápido
14	943700	R14-ROTI-12P	Carcasa Izquierda
15	ACC		Baterías 12 VCD
16	943701	R16-ROTI-12P	Palanca de cambio de velocidades
17	943702	R17-ROTI-12P	Guía de Palanca
18	943703	R18-ROTI-12P	Carcasa Derecha
19	943704	R19-ROTI-12P	Tornillo
20	ACC		Cargador de Batería



A

