


A


No.	Código	Clave	Descripción
1	958868	R1-BOS-1-1/2LMP	Resorte de sujeción (Ø87.5X97X3)
2	958869	R2-BOS-1-1/2LMP	Tapa final
3	958870	R3-BOS-1-1/2LMP	Cápsula para aceite
6	958871	R6-BOS-1-1/2LMP	Balero sin tapas (6303)
7	958872	R7-BOS-1-1/2LMP	Rotor
7.1	958873	R7.1-BOS-1-1/2LMP	Balero sin tapas (6203)
8	958874	R8-BOS-1-1/2LMP	Sello mecánico
9	958875	R9-BOS-1-1/2LMP	Ensamble de motor
9.1	958876	R9.1-BOS-1-1/2LMP	Aislante de arnés (5X60)
9.2	958877	R9.2-BOS-1-1/2LMP	Aislante de arnés (6X70)
9.3	958878	R9.3-BOS-1-1/2LMP	Papel aislante
11	958879	R11-BOS-1-1/2LMP	Tornillo cabeza plana (M5X12)
12	958880	R12-BOS-1-1/2LMP	Casquillo
13	958881	R13-BOS-1-1/2LMP	Sello (Ø84X91X3.5)
14	958882	R14-BOS-1-1/2LMP	Cabezal del cilindro de aceite
14.1	958883	R14.1-BOS-1-1/2LMP	Cubierta del cabezal
15	958884	R15-BOS-1-1/2LMP	Sello (Ø7X13X3)
16	958885	R16-BOS-1-1/2LMP	Tornillo (M8X8)
17	958886	R17-BOS-1-1/2LMP	Tornillo (M8X30)
18	958887	R18-BOS-1-1/2LMP	Arandela de presión (Ø8)
19	958888	R19-BOS-1-1/2LMP	Tuerca M8
20	958889	R20-BOS-1-1/2LMP	Anillo estacionario
21	958890	R21-BOS-1-1/2LMP	Arandela plana (Ø16X20X.5)
22	958891	R22-BOS-1-1/2LMP	Tapa a prueba de arena
23	958892	R23-BOS-1-1/2LMP	Opresor de cable
25	958893	R25-BOS-1-1/2LMP	Cable
25.1	958894	R25.1-BOS-1-1/2LMP	Cubre fillos



A

B

No.	Código	Clave	Descripción
26	958895	R26-BOS-1-1/2LMP	Filtro de malla
27	958896	R27-BOS-1-1/2LMP	Tornillo (M5X8)
28	958897	R28-BOS-1-1/2LMP	Soporte de succión
29	958898	R29-BOS-1-1/2LMP	Tornillo (M4.8X8)
30	958899	R30-BOS-1-1/2LMP	Abrazadera
31	958900	R31-BOS-1-1/2LMP	Cuerpo de bomba
32	958901	R32-BOS-1-1/2LMP	Guarda de cable
32.1	958902	R32.1-BOS-1-1/2LMP	Protector de cable
33	958903	R33-BOS-1-1/2LMP	Tornillo cabeza plana (M6X12)
34	958904	R34-BOS-1-1/2LMP	Acoplamiento del eje
35	958905	R35-BOS-1-1/2LMP	Camisa del eje
36	958906	R36-BOS-1-1/2LMP	Eje (12X281)
37	958907	R37-BOS-1-1/2LMP	Impulsor
38	958908	R38-BOS-1-1/2LMP	Tapa difusora
39	958909	R39-BOS-1-1/2LMP	Sello
40	958910	R40-BOS-1-1/2LMP	Tapa de difusor
41	958911	R41-BOS-1-1/2LMP	Manga
42	958912	R42-BOS-1-1/2LMP	Tornillo hexagonal (M6X12)
43	958913	R43-BOS-1-1/2LMP	Cojinete de goma
44	958914	R44-BOS-1-1/2LMP	Soporte
45	958915	R45-BOS-1-1/2LMP	Válvula de retención
46	958916	R46-BOS-1-1/2LMP	Salida
46.1	958917	R46.1-BOS-1-1/2LMP	Sello (Ø70X74X2)



B

C

No.	Código	Clave	Descripción
1	958918	R1C-BOS-1-1/2LMP	Tornillo (St4X18)
2	958919	R2C-BOS-1-1/2LMP	Tapa de la caja de control
3	958920	R3C-BOS-1-1/2LMP	Soporte del capacitor
4	958921	R4C-BOS-1-1/2LMP	Capacitor 45µF
5	958922	R5C-BOS-1-1/2LMP	Conjunto de terminales del protector térmico
6	958923	R6C-BOS-1-1/2LMP	Protector térmico
7	958924	R7C-BOS-1-1/2LMP	Interruptor
8	958925	R8C-BOS-1-1/2LMP	Conjunto de terminales del campo
9	958926	R9C-BOS-1-1/2LMP	Tableta de conexiones
10	958927	R10C-BOS-1-1/2LMP	Tornillo (St3X20)
11	958928	R11C-BOS-1-1/2LMP	Opresor de cable
12	958929	R12C-BOS-1-1/2LMP	Tornillo (St4X16)
13	958930	R13C-BOS-1-1/2LMP	Protector de cable
14	958931	R14C-BOS-1-1/2LMP	Tuerca plástica
15	958932	R15C-BOS-1-1/2LMP	Cable de alimentación
16	958933	R16C-BOS-1-1/2LMP	Caja de control

C

