


A


No.	Código	Clave	Descripción
1	959003	R1-BOS-1LMP	Resorte de sujeción (Ø87.5X97X3)
2	959004	R2-BOS-1LMP	Tapa final
3	959005	R3-BOS-1LMP	Cápsula para aceite
6	959006	R6-BOS-1LMP	Balero sin tapas (6203)
6.1	958806	R6.1-BOS-3/4LMP	Arandela plana (Ø30X40X.5)
7	959007	R7-BOS-1LMP	Rotor
8	959008	R8-BOS-1LMP	Sello mecánico
8.1	959009	R8.1-BOS-1LMP	Arandela plana (Ø17X28X2)
9	959010	R9-BOS-1LMP	Ensamble de motor
9.1	959011	R9.1-BOS-1LMP	Aislante de arnés (5X60)
9.2	959012	R9.2-BOS-1LMP	Aislante de arnés (6X70)
9.3	959013	R9.3-BOS-1LMP	Papel aislante
11	959014	R11-BOS-1LMP	Tornillo cabeza plana (M5X12)
12	959015	R12-BOS-1LMP	Casquillo
13	959016	R13-BOS-1LMP	Sello (Ø84X91X3.5)
14	959017	R14-BOS-1LMP	Cabezal del cilindro de aceite
14.1	959018	R14.1-BOS-1LMP	Cubierta del cabezal
15	959019	R15-BOS-1LMP	Sello (Ø7X13X3)
16	959020	R16-BOS-1LMP	Tornillo (M8X8)
17	959021	R17-BOS-1LMP	Tornillo (M8X30)
18	959022	R18-BOS-1LMP	Arandela de presión (Ø8)
19	959023	R19-BOS-1LMP	Tuerca M8
20	959024	R20-BOS-1LMP	Anillo estacionario
21	959025	R21-BOS-1LMP	Arandela plana (Ø16X20X.5)
22	959026	R22-BOS-1LMP	Tapa a prueba de arena
23	959027	R23-BOS-1LMP	Sujetador de cables
25	959028	R25-BOS-1LMP	Cable
25.1	959029	R25.1-BOS-1LMP	Cubre filis



A

B

No.	Código	Clave	Descripción
26	959030	R26-BOS-1LMP	Filtro de malla
27	959031	R27-BOS-1LMP	Tornillo (M5X8)
28	959032	R28-BOS-1LMP	Soporte de succión
29	959033	R29-BOS-1LMP	Tornillo (M4.8X8)
30	959034	R30-BOS-1LMP	Abrazadera
31	959035	R31-BOS-1LMP	Cuerpo de bomba
32	959036	R32-BOS-1LMP	Guarda de cable
32.1	959037	R32.1-BOS-1LMP	Protector de cable
33	959038	R33-BOS-1LMP	Tornillo cabeza plana (M6X12)
34	959039	R34-BOS-1LMP	Acoplamiento del eje
35	959040	R35-BOS-1LMP	Camisa del eje
36	959041	R36-BOS-1LMP	Eje (12X215)
37	959042	R37-BOS-1LMP	Impulsor
38	959043	R38-BOS-1LMP	Tapa difusora
39	959044	R39-BOS-1LMP	Sello
40	959045	R40-BOS-1LMP	Tapa de difusor
41	959046	R41-BOS-1LMP	Manga
42	959047	R42-BOS-1LMP	Tornillo hexagonal (M6X12)
43	959048	R43-BOS-1LMP	Cojinete de goma
44	959049	R44-BOS-1LMP	Soporte
45	959050	R45-BOS-1LMP	Válvula de retención
46	959051	R46-BOS-1LMP	Salida
46.1	959052	R46.1-BOS-1LMP	Sello (Ø70X74X2)



B

C

No.	Código	Clave	Descripción
1	959053	R1C-BOS-1LMP	Tornillo (St4X18)
2	959054	R2C-BOS-1LMP	Tapa de la caja de control
3	959055	R3C-BOS-1LMP	Soporte del capacitor
4	959056	R4C-BOS-1LMP	Capacitor 40µF
5	959057	R5C-BOS-1LMP	Conjunto de terminales del protector térmico
6	959058	R6C-BOS-1LMP	Protector térmico
7	959059	R7C-BOS-1LMP	Interruptor
8	959060	R8C-BOS-1MP	Conjunto de terminales del campo
9	959061	R9C-BOS-1LMP	Tableta de conexiones
10	959062	R10C-BOS-1LMP	Tornillo (St3X24)
11	959063	R11C-BOS-1LMP	Opresor de cable
12	959064	R12C-BOS-1LMP	Tornillo (St4X16)
13	959065	R13C-BOS-1LMP	Protector de cable
14	959066	R14C-BOS-1LMP	Tuerca plástica
15	959067	R15C-BOS-1LMP	Cable de alimentación
16	959068	R16C-BOS-1MP	Caja de control

C

