


A

No.	Código	Clave	Descripción
1	958802	R1-BOS-3/4LMP	Resorte de sujeción (Ø87.5X97X3)
2	958803	R2-BOS-3/4LMP	Tapa final
3	958804	R3-BOS-3/4LMP	Cápsula para aceite
6	958805	R6-BOS-3/4LMP	Balero sin tapas (6203)
6.1	958806	R6.1-BOS-3/4LMP	Arandela plana (Ø30X40X.5)
7	958807	R7-BOS-3/4LMP	Rotor
8	958808	R8-BOS-3/4LMP	Sello mecánico
9	958809	R9-BOS-3/4LMP	Ensamble de motor
9.1	958810	R9.1-BOS-3/4LMP	Aislante de arnés (5X60)
9.2	958811	R9.2-BOS-3/4LMP	Aislante de arnés (6X70)
9.3	958812	R9.3-BOS-3/4LMP	Papel aislante
11	958813	R11-BOS-3/4LMP	Tornillo cabeza plana (M5X12)
12	958814	R12-BOS-3/4LMP	Casquillo
13	958815	R13-BOS-3/4LMP	Sello (Ø84X91X3.5)
14	958816	R14-BOS-3/4LMP	Cabezal del cilindro de aceite
14.1	958817	R14.1-BOS-3/4LMP	Cubierta del cabezal
15	958818	R15-BOS-3/4LMP	Sello (Ø7X13X3)
16	958819	R16-BOS-3/4LMP	Tornillo (M8X8)
17	958820	R17-BOS-3/4LMP	Tornillo (M8X30)
18	958821	R18-BOS-3/4LMP	Arandela de presión (Ø8)
19	958822	R19-BOS-3/4LMP	Tuerca M8
20	958823	R20-BOS-3/4LMP	Anillo estacionario
21	958824	R21-BOS-3/4LMP	Arandela plana (Ø16X20X.5)
22	958825	R22-BOS-3/4LMP	Tapa a prueba de arena
23	958826	R23-BOS-3/4LMP	Opresor de cable
25	958827	R25-BOS-3/4LMP	Cable
25.1	958828	R25.1-BOS-3/4LMP	Cubre fillos




A



B

No.	Código	Clave	Descripción
26	958829	R26-BOS-3/4LMP	Filtro de malla
27	958830	R27-BOS-3/4LMP	Tornillo (M5X8)
28	958831	R29-BOS-3/4LMP	Soporte de succión
29	958832	R1-4-DES-52P	Tornillo (M4.8X8)
30	958833	R30-BOS-3/4LMP	Abrazadera
31	958834	R31-BOS-3/4LMP	Cuerpo de bomba
32	958835	R32-BOS-3/4LMP	Guarda de cable
32.1	958836	R32.1-BOS-3/4LMP	Protector de cable
33	958837	R33-BOS-3/4LMP	Tornillo cabeza plana (M6X12)
34	958838	R34-BOS-3/4LMP	Acoplamiento del eje
35	958839	R35-BOS-3/4LMP	Camisa del eje
36	958840	R36-BOS-3/4LMP	Eje (12X215)
37	958841	R37-BOS-3/4LMP	Impulsor
38	958842	R38-BOS-3/4LMP	Tapa difusora
39	958843	R39-BOS-3/4LMP	Sello
40	958844	R40-BOS-3/4LMP	Tapa de difusor
41	958845	R41-BOS-3/4LMP	Manga
42	958846	R42-BOS-3/4LMP	Tornillo hexagonal (M6X12)
43	958847	R43-BOS-3/4LMP	Cojinete de goma
44	958848	R44-BOS-3/4LMP	Soporte
45	958849	R45-BOS-3/4LMP	Válvula de retención
46	958850	R46-BOS-3/4LMP	Salida
46.1	958851	R46.1-BOS-3/4LMP	Sello (Ø70X74X2)



B

C

No.	Código	Clave	Descripción
1	958852	R1C-BOS-3/4LMP	Tornillo (St4X18)
2	958853	R2C-BOS-3/4LMP	Tapa de la caja de control
3	958854	R3C-BOS-3/4LMP	Soporte del capacitor
4	958855	R4C-BOS-3/4LMP	Capacitor 40µF
5	958856	R5C-BOS-3/4LMP	Conjunto de terminales del protector térmico
6	958857	R6C-BOS-3/4LMP	Protector térmico
7	958858	R7C-BOS-3/4LMP	Interruptor
8	958859	R8C-BOS-3/4LMP	Conjunto de terminales del campo
9	958860	R9C-BOS-3/4LMP	Tableta de conexiones
10	958861	R10C-BOS-3/4LMP	Tornillo (St3X24)
11	958862	R11C-BOS-3/4LMP	Opresor de cable
12	958863	R12C-BOS-3/4LMP	Tornillo (St4X16)
13	958864	R13C-BOS-3/4LMP	Protector de cable
14	958865	R14C-BOS-3/4LMP	Tuerca plástica
15	958866	R15C-BOS-3/4LMP	Cable de alimentación
16	958867	R16C-BOS-3/4LMP	Caja de control

C

