


A

No.	Código	Clave	Descripción
1	958737	R1-BOS-1/2LMP	Resorte de sujeción (Ø87.5X97X3)
2	958738	R2-BOS-1/2LMP	Tapa final
3	958739	R3-BOS-1/2LMP	Cápsula para aceite
6	958740	R6-BOS-1/2LMP	Balero sin tapas (6203)
7	958741	R7-BOS-1/2LMP	Rotor
8	958742	R8-BOS-1/2LMP	Sello mecánico
9	958743	R9-BOS-1/2LMP	Ensamble de motor
9.1	958744	R9.1-BOS-1/2LMP	Aislante de arnés (5X60)
9.2	958745	R9.2-BOS-1/2LMP	Aislante de arnés (6X70)
9.3	958746	R9.3-BOS-1/2LMP	Papel aislante
11	958747	R11-BOS-1/2LMP	Tornillo cabeza plana (M5X12)
12	958748	R12-BOS-1/2LMP	Casquillo
13	958749	R13-BOS-1/2LMP	Sello (Ø84X91X3.5)
14	958750	R14-BOS-1/2LMP	Cabezal del cilindro de aceite
14.1	958751	R14.1-BOS-1/2LMP	Cubierta del cabezal
15	958752	R15-BOS-1/2LMP	Sello (Ø7X13X3)
16	958753	R16-BOS-1/2LMP	Tornillo (M8X8)
17	958754	R17-BOS-1/2LMP	Tornillo (M8X30)
18	958755	R18-BOS-1/2LMP	Arandela de presión (Ø8)
19	958756	R19-BOS-1/2LMP	Tuerca M8
20	958757	R20-BOS-1/2LMP	Anillo estacionario
21	958758	R21-BOS-1/2LMP	Arandela plana (Ø16X20X.5)
22	958759	R22-BOS-1/2LMP	Tapa a prueba de arena
23	958760	R23-BOS-1/2LMP	Sujetador de cables
25	958761	R25-BOS-1/2LMP	Cable
25.1	958762	R25.1-BOS-1/2LMP	Cubre filós




A



B

No.	Código	Clave	Descripción
26	958763	R26-BOS-1/2LMP	Filtro de malla
27	958764	R27-BOS-1/2LMP	Tornillo (M5X8)
28	958765	R28-BOS-1/2LMP	Soporte de succión
29	958766	R29-BOS-1/2LMP	Tornillo (M4.8X8)
30	958767	R30-BOS-1/2LMP	Abrazadera
31	958768	R31-BOS-1/2LMP	Cuerpo de bomba
32	958769	R32-BOS-1/2LMP	Guarda de cable
32.1	958770	R32.1-BOS-1/2LMP	Protector de cable
33	958771	R33-BOS-1/2LMP	Tornillo cabeza plana (M6X12)
34	958772	R34-BOS-1/2LMP	Acoplamiento del eje
35	958773	R35-BOS-1/2LMP	Camisa del eje
36	958774	R36-BOS-1/2LMP	Eje (12X156)
37	958775	R37-BOS-1/2LMP	Impulsor
38	958776	R38-BOS-1/2LMP	Tapa difusora
39	958777	R39-BOS-1/2LMP	Sello
40	958778	R40-BOS-1/2LMP	Tapa de difusor
41	958779	R41-BOS-1/2LMP	Manga
42	958780	R42-BOS-1/2LMP	Tornillo hexagonal (M6X12)
43	958781	R43-BOS-1/2LMP	Cojinete de goma
44	958782	R44-BOS-1/2LMP	Soporte
45	958783	R45-BOS-1/2LMP	Válvula de retención
46	958784	R46-BOS-1/2LMP	Salida
46.1	958785	R46.1-BOS-1/2LMP	Sello (Ø70X74X2)



B

C

No.	Código	Clave	Descripción
1	958786	R1C-BOS-1/2LMP	Tornillo (St4X18)
2	958787	R2C-BOS-1/2LMP	Tapa de la caja de control
3	958788	R3C-BOS-1/2LMP	Soporte del capacitor
4	958789	R4C-BOS-1/2LMP	Capacitor 35µF
5	958790	R5C-BOS-1/2LMP	Conjunto de terminales del protector térmico
6	958791	R6C-BOS-1/2LMP	Protector térmico
7	958792	R7C-BOS-1/2LMP	Interruptor
8	958793	R8C-BOS-1/2LMP	Conjunto de terminales del campo
9	958794	R9C-BOS-1/2LMP	Tableta de conexiones
10	958795	R10C-BOS-1/2LMP	Tornillo (St3X20)
11	958796	R11C-BOS-1/2LMP	Opresor de cable
12	958797	R12C-BOS-1/2LMP	Tornillo (St4X16)
13	958798	R13C-BOS-1/2LMP	Protector de cable
14	958799	R14C-BOS-1/2LMP	Tuerca plástica
15	958800	R15C-BOS-1/2LMP	Cable de alimentación
16	958801	R16C-BOS-1/2LMP	Caja de control

C

