


A

No.	Código	Clave	Descripción
1	934675	R1-MOT-4520P	Tornillo St5x9
2	934676	R2-MOT-4520P	Tanque de combustible
3	934677	R3-MOT-4520P	Sub ensamble de tapa
4	934678	R4-MOT-4520P	Sello
5	934679	R5-MOT-4520P	Tapón combustible
6	9346780	R6-MOT-4520P	Almohadilla de goma
7	934681	R7-MOT-4520P	Tornillo
8	934682	R8-MOT-4520P	Tapón
9	934683	R9-MOT-4520P	Amortiguador plástico
10	934684	R10-MOT-4520P	Tornillo St 8x16
11	934685	R11-MOT-4520P	Empuñadura
12	934686	R12-MOT-4520P	Bulbo cebador
13	934687	R13-MOT-4520P	Seguro del acelerador
14	934688	R14-MOT-4520P	Resorte del acelerador
15	934689	R15-MOT-4520P	Acelerador
16	934690	R16-MOT-4520P	Perno de acelerador
17	934691	R17-MOT-4520P	Cubierta de la empuñadura
18	934692	R18-MOT-4520P	Tubo de re retorno de aceite
19	934693	R19-MOT-4520P	Equilibrador
20	934694	R20-MOT-4520P	Balancín
21	934695	R21-MOT-4520P	Filtro de combustible
22	934696	R22-MOT-4520P	Casco de filtro de combustible
23	934697	R23-MOT-4520P	Manguera de combustible
24	934698	R24-MOT-4520P	Cojinete reductor de impacto
25	934699	R25-MOT-4520P	Tornillo M5x50
26	934700	R26-MOT-4520P	Conector al carburador
27	934701	R27-MOT-4520P	Perno
28	934702	R28-MOT-4520P	Varilla de acelerador
29	934703	R29-MOT-4520P	Cubierta superior
30	934704	R30-MOT-4520P	Tornillo M5x14


A



B

No.	Código	Clave	Descripción
31	934705	R31-MOT-4520P	Junta de filtro de aire
32	934706	R31-MOT-4520P	Filtro de aire
33	934707	R33-MOT-4520P	Cubierta del filtro de aire
34	934708	R34-MOT-4520P	Junta de la perilla del filtro de aire
35	934709	R35-MOT-4520P	Perilla del filtro de aire
36	934710	R36-MOT-4520P	Manguera entrada de aceite
37	934711	R37-MOT-4520P	Resorte de manguera entrada de aceite
38	934712	R38-MOT-4520P	Carburador
39	934713	R39-MOT-4520P	Brida del carburador
40	934714	R40-MOT-4520P	Junta de aislamiento
41	934715	R41-MOT-4520P	Soporte del carburador
42	934716	R42-MOT-4520P	Hoja de aislamiento
43	934717	R43-MOT-4520P	Tornillo Xt 4.2x12
44	934718	R44-MOT-4520P	Almohadilla de goma
45	934719	R45-MOT-4520P	Perilla de estrangulación
46	934720	R46-MOT-4520P	Cubierta perilla de estrangulación
47	934721	R47-MOT-4520P	Almohadilla de goma
48	934722	R48-MOT-4520P	Almohadilla de goma derecha
49	934723	R49-MOT-4520P	Ensamble derecho de cárter
50	934724	R50-MOT-4520P	Soporte de plástico
51	934725	R51-MOT-4520P	Balero de bolas 6202
52	934726	R52-MOT-4520P	Malla filtro de aceite
53	934727	R53-MOT-4520P	Soporte del filtro de aceite
54	934728	R54-MOT-4520P	Retén 15x25x4.5
55	934729	R55-MOT-4520P	Sello de esponja
56	934730	R56-MOT-4520P	Manguera al filtro de aire
57	934731	R57-MOT-4520P	Bomba de aceite
58	934732	R58-MOT-4520P	Ensamble de clutch
61	934733	R61-MOT-4520P	Arandel del clutch
62	934734	R62-MOT-4520P	Tambor del clutch


B



C

No.	Código	Clave	Descripción
63	934735	R63-MOT-4520P	Rueda dentada
64	934736	R64-MOT-4520P	Balero de agujas
65	934737	R65-MOT-4520P	Engrane
66	934738	R66-MOT-4520P	Tornillo M4x12
67	934739	R67-MOT-4520P	Cubierta de la bomba de aceite
68	934740	R68-MOT-4520P	Salida de la bomba de aceite
69	934741	R69-MOT-4520P	Tornillo M5x20
70	934742	R70-MOT-4520P	Colector de cadena
71	934743	R71-MOT-4520P	Soporte del amortiguador
72	934744	R73-MOT-4520P	Amortiguador
73	934745	R73-MOT-4520P	Tornillo M4x10
74	934746	R74-MOT-4520P	Cubierta de la salida de aceite
74.1	934747	R74.1-MOT-4520P	Separador
75	934748	R74-MOT-4520P	Soporte derecho
76	934749	R76-MOT-4520P	Perno con cuerda
77	934750	R77-MOT-4520P	Espiga
78	934751	R78-MOT-4520P	Filtro de la aguja de respirador
79	934752	R79-MOT-4520P	Seguro de la aguja
80	934753	R80-MOT-4520P	Aguja de respiración
81	934754	R81-MOT-4520P	Aro de carburador
82	934755	R82-MOT-4520P	Tornillo M5x14
83	934756	R83-MOT-4520P	Manga de entrada
84	934757	R84-MOT-4520P	Bujía
85	934758	R85-MOT-4520P	Junta
86	934759	R86-MOT-4520P	Cilindro
87	934760	R87-MOT-4520P	Tornillo M5x87
88	934761	R88-MOT-4520P	Junta del mofle
89	934762	R89-MOT-4520P	Mofle
90	934763	R90-MOT-4520P	Tornillo M5x10
91	934764	R91-MOT-4520P	Cubierta de mofle


C



D

No.	Código	Clave	Descripción
92	934765	R92-MOT-4520P	Tuerca M5
93	934766	R93-MOT-4520P	Junta del cilindro
94	934767	R94-MOT-4520P	Anillo del pistón
95	934768	R95-MOT-4520P	Perno del pistón
96	934769	R96-MOT-4520P	Pistón
97	934770	R97-MOT-4520P	Seguro del perno de pistón
98	934771	R98-MOT-4520P	Balero de agujas 11x15x12.5 mm
99	934772	R99-MOT-4520P	Ensamble de la biela y cigüeñal
100	934773	R100-MOT-4520P	Arandela espaciadora
101	934774	R101-MOT-4520P	Cuña 3x10
102	934775	R102-MOT-4520P	Perno
103	934776	R103-MOT-4520P	Junta del cárter
104	934777	R104-MOT-4520P	Abrazadera de la manguera
105	934778	R105-MOT-4520P	Ensamble de la manguera
107	934779	R107-MOT-4520P	Cable del switch
108	934780	R108-MOT-4520P	Bobina de ignición
109	934781	R109-MOT-4520P	Tornillo M5x20
110	934782	R110-MOT-4520P	Tornillo M5x25
111	934783	R111-MOT-4520P	Tornillo M5x30
112	934784	R112-MOT-4520P	Sello del tapón de aceite
113	934785	R113-MOT-4520P	Tapón de aceite
114	934786	R114-MOT-4520P	Seguro
115	934787	R115-MOT-4520P	Retén 15x35x4.5
116	934788	R116-MOT-4520P	Tapa
117	934789	R117-MOT-4520P	Tornillo M4x6
118	934790	R118-MOT-4520P	Rotor
119	934791	R119-MOT-4520P	Tuerca M8
120	934792	R120-MOT-4520P	Alojamiento de interruptor
121	934793	R121-MOT-4520P	Soporte del interruptor


D



E

No.	Código	Clave	Descripción
122	934794	R122-MOT-4520P	Interruptor
123	934795	R123-MOT-4520P	Almohadilla de goma exterior
124	934796	R124-MOT-4520P	Almohadilla de goma izquierda
125	934797	R125-MOT-4520P	Ensamble izquierdo del carter
126	934798	R126-MOT-4520P	Seguro Ø3
128	934799	R128-MOT-4520P	Perno 3x9
129	934800	R129-MOT-4520P	Freno del muelle del empujador A
130	934801	R130-MOT-4520P	Perno 3x8
131	934802	R131-MOT-4520P	Tuerca hexagonal M8
132	934803	R132-MOT-4520P	Freno de muelle del empujador B
133	934804	R133-MOT-4520P	Amortiguador
134	934805	R134-MOT-4520P	Tapa del clutch
135	934806	R135-MOT-4520P	Correa de caucho
136	934807	R136-MOT-4520P	Resorte Actuador I
137	934808	R137-MOT-4520P	Resorte Actuador II
138	934809	R138-MOT-4520P	Freno
139	934810	R139-MOT-4520P	Cubierta del resorte
140	934811	R140-MOT-4520P	Tornilla St 4.2x9.5
141	934812	R141-MOT-4520P	Placa de la barra
142	934813	R142-MOT-4520P	Seguro Ø4
143	934814	R143-MOT-4520P	Arandela plana
144	934815	R144-MOT-4520P	Ensamble del freno I
145	934816	R145-MOT-4520P	Aro de hule
146	934817	R146-MOT-4520P	Ensamble del freno II
147	934818	R147-MOT-4520P	Diente de ajuste
148	934819	R148-MOT-4520P	Sin fin de ajuste
149	934820	R149-MOT-4520P	Resorte del freno
150	934821	R150-MOT-4520P	Rueda dentan de ajuste
151	934822	R151-MOT-4520P	Pin hueco
152	934823	R152-MOT-4520P	Pin de nivel I

E



F

No.	Código	Clave	Descripción
153	934824	R153-MOT-4520P	Pin de nivel II
154	934825	R154MOT-4520P	Freno
155	934826	R155-MOT-4520P	Deflector
156	934827	R156-MOT-4520P	Arandela
157	934828	R157-MOT-4520P	Cubierta principal de sistema de arranque
158	934829	R158-MOT-4520P	Resorte principal del sistema de arranque
159	934830	R159-MOT-4520P	Polea de arranque
160	934831	R160-MOT-4520PMP	Cubierta de arranque
161	934832	R161-MOT-4520P	Resorte de la cubierta de arranque
162	934833	R162-MOT-4520P	Protector plástico
163	934834	R163-MOT-4520PP	Cubierta del sistema de arranque
164	934835	R164-MOT-4520P	Cuerda
165	934836	R165-MOT-4520P	Empuñadura de arranque

F

