


A

No.	Código	Clave	Descripción
1	959320	R1-BAS-100PLAP	Etiqueta de visualización frontal y trasera
2	959321	R2-BAS-100PLAP	Cubierta frontal
3	959322	R3-BAS-100PLAP	Panel frontal de plástico
4	959323	R4-BAS-100PLAP	Tornillo cabeza plana (St3X8)
5	959324	R5-BAS-100PLAP	Conjunto de pantalla delantera y trasera con arnés
6	959325	R6-BAS-100PLAP	Tornillo (St3X5)
7	959326	R7-BAS-100PLAP	Carcasa trasera
8	959327	R8-BAS-100PLAP	Panel de plástico trasero
9	959328	R9-BAS-100PLAP	Teclado con arnés
11	959329	R11-BAS-100PLAP	Tarjeta principal
12	959330	R12-BAS-100PLAP	Tornillo (M4X8)
13	959331	R13-BAS-100PLAP	Tornillo (St3X6)
14	959332	R14-BAS-100PLAP	Set de cables
15	959333	R15-BAS-100PLAP	Centro de carga
16	959334	R16-BAS-100PLAP	Interruptor
17	959335	R17-BAS-100PLAP	Batería
18	959336	R18-BAS-100PLAP	Set de cables de batería
19	959337	R19-BAS-100PLAP	Soporte de batería
20	959338	R20-BAS-100PLAP	Protector de cable



A



B

No.	Código	Clave	Descripción
21	959339	R21-BAS-100PLAP	Chasis inferior con brazo
22	959340	R22-BAS-100PLAP	Pata de chasis (M7X16)
23	959341	R23-BAS-100PLAP	Celda de carga
24	959342	R24-BAS-100PLAP	Tornillo Allen (M8X23)
25	959343	R25-BAS-100PLAP	Chasis superior
26	959344	R26-BAS-100PLAP	Placa de carga



B

