






A	No.	Código	Clave	Descripción
	1	955983	R1A-MOT-50-16-18-20	Cubierta frontal
	2	955984	R2A-MOT-50-16-18-20	Manga
	3	955985	R3A-MOT-50-16-18-20	Seguro C (Ø15X18X1)
	4	955986	R4A-MOT-50-16-18-20	Tornillo (St3.5X15.5)
	6	955987	R6A-MOT-50-16-18-20	Anillo de posicionamiento del balín
	8	955988	R8A-MOT-50-16-18-20	Anillo (Ø21X32X5)
	10	955989	R10A-MOT-50-16-18-20	Balín (Ø7)
	12	955990	R12A-MOT-50-16-18-20	Anillo de bloqueo de balín (Ø16X31X1)
	13	955991	R13A-MOT-50-16-18-20	Resorte de bloqueo
	14	955992	R14A-MOT-50-16-18-20	Anillo C (Ø23X28X1.5)
	15	955993	R15A-MOT-50-16-18-20	Balero 6805
	16	955994	R16A-MOT-50-16-18-20	Arandela de amortiguación (Ø25X32X5)
	23	955995	R23A-MOT-50-16-18-20	Sello para grasa (Ø27X37X6.5)
	24	955996	R24A-MOT-50-16-18-20	Manga rotativa
	25	955997	R25A-MOT-50-16-18-20	Anillo C (Ø24.5X27.5X1.5)
	26	955998	R26A-MOT-50-16-18-20	Embrague




C	No.	Código	Clave	Descripción
	1	955999	R1C-MOT-50-16-18-20	Tornillo torx (ST 4X10)
	2	956000	R2C-MOT-50-16-18-20	Soporte
	3	956001	R3C-MOT-50-16-18-20	Seguro de la cubierta
	4	956002	R4C-MOT-50-16-18-20	Cubierta del filtro de aire



E

No.	Código	Clave	Descripción
1.1	956003	R1.1E-MOT-50-16-18-20	Cilindro
1.2	956004	R1.2E-MOT-50-16-18-20	Anillos de piston
1.3	956005	R1.3E-MOT-50-16-18-20	Piston
1.4	956006	R1.4E-MOT-50-16-18-20	Cigüeñal
1.5	956007	R1.5E-MOT-50-16-18-20	Perno de piston (10X29)
1.6	956008	R1.6E-MOT-50-16-18-20	Seguro de piston
1.7	956009	R1.7E-MOT-50-16-18-20	Sello de aceite (Ø12X32X6)
1.8	956010	R1.8E-MOT-50-16-18-20	Balero 6201
1.9	956011	R1.9E-MOT-50-16-18-20	Soporte de Clutch
1.10	956012	R1.10E-MOT-50-16-18-20	Buje (10X13X15.5)
1.11	956013	R1.11E-MOT-50-16-18-20	Arandela Plan (Ø10X18X1)
1.12	956014	R1.12E-MOT-50-16-18-20	Bomba de aceite
1.13	956015	R1.13E-MOT-50-16-18-20	Tornillo torx (M4X15)
1.14	956016	R1.14E-MOT-50-16-18-20	Placa de bloqueo de cincel
2	956017	R2E-MOT-50-16-18-20	Bujia
3	956018	R3E-MOT-50-16-18-20	Rotor
4	956019	R4E-MOT-50-16-18-20	Arnadela plana (Ø9X17.5X1)
6	956020	R6E-MOT-50-16-18-20	Tuerca M8
7	956021	R7E-MOT-50-16-18-20	Bobina
8	956022	R8E-MOT-50-16-18-20	Tornillo torx (M4X10)


E




F	No.	Código	Clave	Descripción
	1	956023	R1F-MOT-50-16-18-20	Tornillo cabeza cuadrada (M5X72)
	2	956024	R2F-MOT-50-16-18-20	Junta de escape
	3	956025	R3F-MOT-50-16-18-20	Escape
	4	956026	R4F-MOT-50-16-18-20	Deflector, Salida
	5	956027	R5F-MOT-50-16-18-20	Arandela plan (Diam 5.5X16X1.5)
	6	956028	R6F-MOT-50-16-18-20	Tuerca M5




F




G	No.	Código	Clave	Descripción
	1	956029	R1G-MOT-50-16-18-20	Cilindro
	2	956030	R2G-MOT-50-16-18-20	Anillos de piston
	3	956031	R3G-MOT-50-16-18-20	Piston
	4	956032	R4G-MOT-50-16-18-20	Cigüeñal
	5	956033	R5G-MOT-50-16-18-20	Perno de piston (10X29)
	6	956034	R6G-MOT-50-16-18-20	Seguro de piston
	7	956035	R7G-MOT-50-16-18-20	Sello de aceite (Ø12X32X6)
	8	956036	R8G-MOT-50-16-18-20	Balero 6201
	9	956037	R9G-MOT-50-16-18-20	Soporte de Clutch
	10	956038	R10G-MOT-50-16-18-20	Buje (10X13X15.5)
	12	956039	R12G-MOT-50-16-18-20	Arandela Plan (Ø10X18X1)




H	No.	Código	Clave	Descripción
	1	956040	R1H-MOT-50-16-18-20	Tornillo torx (ST 5X9)
	2	956041	R2H-MOT-50-16-18-20	Banda de freno, acero inoxidable
	3	956042	R3H-MOT-50-16-18-20	Resorte para freno
	4	956043	R4H-MOT-50-16-18-20	Perno (3X13)
	5	956044	R5H-MOT-50-16-18-20	Perno (4X13)
	6	956045	R6H-MOT-50-16-18-20	Seguro E (Diam 3.5X10X.8)
	7	956046	R7H-MOT-50-16-18-20	Resorte
	8	956047	R8H-MOT-50-16-18-20	Perno (5X24)
	9	956048	R9H-MOT-50-16-18-20	Plástico, cubierta, freno de cadena
	10	956049	R10H-MOT-50-16-18-20	Freno de cadena
	10.1	956050	R10.1H-MOT-50-16-18-20	Juego de bujes y tornillo del freno
	11	956051	R11H-MOT-50-16-18-20	Ensamble de eslabón de freno de cadena
	12	956052	R12H-MOT-50-16-18-20	Seguro E (6X15.5X.8)
	13	956053	R13H-MOT-50-16-18-20	Conjunto, tambor con piñón
	14	956054	R14H-MOT-50-16-18-20	Arandela plana (Diam 10X38X1.5)
	15	956055	R15H-MOT-50-16-18-20	Conjunto de embrague
	16	956056	R16H-MOT-50-16-18-20	Arandela de copa



No.	Código	Clave	Descripción
1	956057	R1I-MOT-50-16-18-20	Tuerca
2	956058	R2I-MOT-50-16-18-20	Cubierta de la cadena
3	956059	R3I-MOT-50-16-18-20	Buje
4	956060	R4I-MOT-50-16-18-20	Tornillo de ajuste
5	956061	R5I-MOT-50-16-18-20	Engrane de ajuste
6	956062	R6I-MOT-50-16-18-20	Placa de la barra guía
7	956063	R7I-MOT-50-16-18-20	Tornillo St4x18




J	No.	Código	Clave	Descripción
	1	956064	R1J-MOT-50-16-18-20	Mango delantero
	2	956065	R2J-MOT-50-16-18-20	Tornillo torx (5X17)
	3	956066	R3J-MOT-50-16-18-20	Retenedor del resorte
	4	956067	R4J-MOT-50-16-18-20	Tornillo torx (5X19)
	5	956068	R5J-MOT-50-16-18-20	Resorte de Anija
	6	956069	R6J-MOT-50-16-18-20	Tornilo torx (5X35)
	7	956070	R7J-MOT-50-16-18-20	Tapon
	8	956071	R8J-MOT-50-16-18-20	Cubierta del mango
	9	956072	R9J-MOT-50-16-18-20	Gatillo del acelerador
	10	956073	R10J-MOT-50-16-18-20	Resorte de torsion
	11	956074	R11J-MOT-50-16-18-20	Bloqueo del acelerador
	12	956075	R12J-MOT-50-16-18-20	Mango trasero
	12.1	956076	R12.1J-MOT-50-16-18-20	Tronillo torx (5X15)
	12.2	956077	R12.2J-MOT-50-16-18-20	Soporte del resorte
	12.3	956078	R12.3J-MOT-50-16-18-20	Resorte
	12.4	956079	R12.4J-MOT-50-16-18-20	Tornilo torx (M5X16)
	12.5	956080	R12.5J-MOT-50-16-18-20	Union
	13	956081	R13J-MOT-50-16-18-20	Retendor del resorte 2
	14	956082	R14J-MOT-50-16-18-20	Resorte 2
	15	956083	R15J-MOT-50-16-18-20	Tornillo (6X38)
	16	956084	R16J-MOT-50-16-18-20	Buje (5.5X10.5X19)
	17	956085	R17J-MOT-50-16-18-20	Buje de hule (10X15X13)



K

No.	Código	Clave	Descripción
1	956086	R1K-MOT-50-16-18-20	Buje (5.3X9X25)
2	956087	R2K-MOT-50-16-18-20	Anillo de aceite
3	956088	R3K-MOT-50-16-18-20	Tornillo torx (5X13)
4	956089	R4K-MOT-50-16-18-20	Sosten de la cadena
5	956090	R5K-MOT-50-16-18-20	Tornillo de cabeza cuadrada (M8X45)
7	956091	R7K-MOT-50-16-18-20	Manguera de aceite
8	956092	R8K-MOT-50-16-18-20	Tapon de bronce
10	956093	R10K-MOT-50-16-18-20	Manguera (245mm)
11	956094	R11K-MOT-50-16-18-20	Filtro
12	956095	R12K-MOT-50-16-18-20	Resorte
13	956096	R13K-MOT-50-16-18-20	Chasis
14	956097	R14K-MOT-50-16-18-20	Tapon de aceite
15	956098	R15K-MOT-50-16-18-20	Filtro de gasolina
16	956099	R16K-MOT-50-16-18-20	Ensamble de tapon de gasolina
17	956100	R17K-MOT-50-16-18-20	Manguera (170mm)
18	956101	R18K-MOT-50-16-18-20	Tuerca especial



K

L	No.	Código	Clave	Descripción
	1	956102	R1L-MOT-50-16-18-20	Buje (5.3X9X25)
	2	956103	R2L-MOT-50-16-18-20	Anillo de aceite
	3	956104	R3L-MOT-50-16-18-20	Tornillo torx (5X13)
	4	956105	R4L-MOT-50-16-18-20	Sosten de la cadena
	5	956106	R5L-MOT-50-16-18-20	Tornillo de cabeza cuadrada (M8X45)
	6	956107	R6L-MOT-50-16-18-20	Manguera de aceite
	7	956108	R7L-MOT-50-16-18-20	Ahogador

